


Model: SPK303
Bluetooth Speaker & Tablet/Smartphone Stand Combo

PLEASE READ THIS INFORMATION THOROUGHLY BEFORE USING THIS PRODUCT. IT CONTAINS IMPORTANT OPERATING INSTRUCTIONS FOR YOUR SPEAKER.

Owner's Manual

Thank you for purchasing the SPK303 Tablet/Smartphone Bluetooth Speaker. This speaker can easily connect to your tablet, smartphone, or music/audio device via Bluetooth or by cable (included).

Included in the package you have purchased: SPK303 Lenmar Tablet/Smartphone Bluetooth Speaker, USB Charging Cord, Audio Cable and User Manual.



Speaker Controls

Charging Status	
Green LED – Blinking Fast	Low Battery, Please Charge
RED LED	Charging in Process
No LED	Charging Completed

Bluetooth Status	
Green LED – Blinking Slowly	Bluetooth is Disconnected
Green LED – Solid	Bluetooth is Connected to a Device

Charging your Speaker

This device is powered by a rechargeable built-in lithium-polymer battery. Prior to initial use please charge the speaker fully using the included USB to Micro USB cable. You have the option of charging the speaker while connected to a computer or USB wall adapter. The approximate charging time is 4 hours.



Installation


1. Open the lid.
2. Separate the stand.
3. Put the tablet or music/audio device on the stand.
4. Adjust the lid accordingly.

Bluetooth Connection

1. Turn the speaker to the "ON" position, a long beep will be heard followed by two low pitched beeps. Green LED will then flash slowly indicating that the speaker is ready for Bluetooth pairing.
2. Turn "ON" the Bluetooth function of your tablet or music/audio device. Select the device labeled "Bluetooth." When the connection is successful, you will hear one low pitched sound. If necessary, please use passkey or PIN# 0000 (4 zeros) to finish the pairing process. Once the Bluetooth has been connected, the GREEN LED will be solid.


NFC Connection

1. Turn on the NFC and Bluetooth function on your phone.
2. Put your phone close to the NFC logo.
3. Pairing option appears on your phone, confirm by choosing "Yes."



Audio Cable Connections

You may also use the supplied audio cable, rather than the Bluetooth to connect to the speaker.



Precautions

Do not operate speaker near places with frequent static electricity or electrical noise. Do not store in an area that is damp, humid, wet, or near a magnetic field such as near credit cards or video screens. The speaker should remain in temperatures between 59°F and 77°F (or 15°C and 25°C).

Do not use solvents to clean the speaker. A soft cloth or damp chamois leather is best.

If there is a battery leak, discontinue use of the speaker immediately. You may contact Lenmar Enterprises, Inc. for more information about product warranties or repairs.

Please dispose of the speaker and/or batteries according to local regulations. We recommend that you recycle all batteries after use. Do not dispose as household waste. Do not dispose of in a hot or cold place or near exposure to fire as the battery may explode.

Please keep out of reach of children.

Specifications

- Bluetooth v2.1+EDR, CSR BCS
- Amplified Output Power: 2.5W + 2.5W = 5W
- Frequency Response: 50HZ~20 KHz
- S/N: >85db
- Power Supply: Rechargeable Lithium-Polymer Battery / USB Cable
- Battery charging current: 220mA
- Battery Capacity: 850mAh, max 3.1Wh
- Operation voltage min. 3V; max. 4.2V DC
- Battery charging voltage typ. 5V; max. 5.5V DC (via USB port)
- Drain current (power on, no input) typ. 30mA
- Operating range up to 10 meters, plays well in a room up to 50M²
- Impedance: 4 Ohms
- Charging Time: approximate 4 hours
- Standby Time: Up to 30 hours
- Battery playback life up to 4 hours depending on music style and use conditions
- Dimensions: 200mm x 73mm x 32mm
- Weight: 260g

Limited 1 Year Warranty

Lenmar product is warranted to be free of defective parts and workmanship for stated period from the original date of purchase when sold through our website or our authorized retailers. Warranties are not transferable. The warranty excludes damage resulting from accident, misuse, modification, delay or loss of use, damage to equipment or by normal wear and tear.

ALL WARRANTY CLAIMS ARE PROCESSED ONLINE AT THE FOLLOWING LINK:
WWW.LENMAR.COM/WARRANTY

Warranty claims made after 60 days from the original date of purchase, will require a processing fee. Details will be included while completing the online warranty request. Payment can be made via credit card when completing the warranty form or a check can be included with the package when it is returned to Lenmar. Once the request is completed, you will be emailed with a confirmation WRA number and instructions on how to return the item for a warranty replacement.

Proposition 65 Notice (California)

The following statement is required in the state of California pursuant to the settlement of an action brought by the Mateel Environmental Justice Foundation against multiple electronics and appliance manufacturers

• WARNING: Handling the cord on this product will expose you to lead, a chemical known to the state of California to cause birth defects or other reproductive harm. Wash hands after handling.

For additional questions, comments, or to explore other Lenmar power solutions, visit our website at: www.lenmar.com or call 800.424.2703 from 9AM – 5PM PST.

313-119-07-0514 r1 y1

Lithium-Polymer battery must be recycled or disposed of properly.

